



POD Dome Cover Instructions



Replace the existing 3/8" mid wall bolts with 3/8" X 5" eye bolts. Reuse the existing nut and washers.



Gather the cover between you and your POD, with the far side of the cover at the top. Feed the cover up over the dome with your hands.



Walk around the POD and pull the cover into place.

Continued...



POD Dome Cover Instructions - Continued



Rotate the cover around the dome until the grommets line up with the eye bolts in the mid wall.



Use a 15 -18" bungee cable to secure the cover to the POD.



Cover in place and secured.

Removing the cover is even easier

Remove the bungee cables and lift the cover from around the dome flange. Drag the cover off toward you from anywhere around the dome to pull it off. Use a POD Bay to store the cover in when not in use.



POD Dome Cover Instructions - Alternate



If you're having trouble getting the cover over the dome, add a 10' rope, which you can throw over the dome and then pull the cover up and over from the opposite side of the POD .

You still have to get the cover into place and lined up correctly so that when you pull the rope from the opposite side, the cover opens up and covers the dome as you pull on the rope.

The rope pictured here is a little shorter than optimal at only about 6'. A 10' rope is easier to throw over the dome.



Using the rope to pull the cover all the way down into place.

You'll find that you can also move the cover around on the dome as you're pulling it down.

It may take a couple of tries to get the knack, but once you get it you'll find it easier each time you cover your POD

If you have any questions or problems please email us at support@skyshedpod.com
or call 519-345-0036